

FITTING THE CASTORS TO FRONT (RAM) END OF LIFT TO IMPROVE MANOUEVERABILITY.

IT IS NOT ADVISABLE TO RAISE OR LOWER A CAR WITH CASTORS ON !!

The fitting of these castors is your option and are easy to remove when not required.

Care has to be taken when moving the lift this way, as the hose and safety cable are still connected and can pull the trolley over and damage the power pack, or trap the hose. The castors are easy to fit, and only need bolting corner to corner. We have used two, 8mm bolts, just finger tightened.

You could also place the trolley with the motor on the top of the lift, (on a board to avoid damage to power pack. ?!) and pull the lift with a rope



It is possible to raise the lift 6 to 12 inches, to give a little more ground clearance, without making too much difference to the angle of working castor.



The heavy duty nylon castors, colour may vary, will take a load of 200kg per castor.



IT IS NOT ADVISABLE TO RAISE OR LOWER A CAR WITH CASTORS ON !!